



SERVICE MANUAL

for the

***Kodak X-Omat* 180 LP SORTER**



PLEASE NOTE The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.

Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from any use of this information, even if loss or damage is caused by Kodak's negligence or other fault.



This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.

Table of Contents

Description	Page
Adjustments and Replacements	1-1
Special Tools Required	1-2
Electrostatic Discharge	1-2
Overview	1-2
Preventive Measures	1-2
Service Overview	1-3
Position and Identification of Subassemblies	1-3
De-energizing and Energizing the PROCESSOR	1-5
General Access to the SORTER or to the PROCESSOR	1-6
Installing the TOP COVER	1-7
* Adjusting the ACCESS DOOR LATCHES — See the Processor Installation section	
* Leveling the PROCESSOR — See the Processor Installation section	
* Measuring and Adjusting the Height of the SORTER — See the Processor Installation section	
Replacement of the DIVERTERS or the BEARINGS	1-8
Replacement of a SOLENOID	1-9
Replacement of the INTERLOCK SWITCH	1-10
Replacement of a MODULE	1-11
Replacement of the SENSOR on a MODULE	1-12
Replacement of the ROLLERS on a LEAD or MAIN MODULE or on the ACCESS DOOR	1-14
Replacement of the IDLER ROLLERS and SPRINGS on a MODULE	1-16
Replacement of the BIN ROLLER	1-17
Replacement of the Front BEARING	1-17
Replacement of the GEAR or the Back BEARING	1-18
Replacement and Adjustment of the DRIVE BELT	1-19
Replacement of the DRIVE MOTOR or the GEARBOX	1-20
Replacement of the MAIN DRIVE SHAFT	1-21
Replacement of the WORM GEARS	1-22
Replacement of the GAS SPRING	1-23
Replacement of the 4000 BOARD or MOTOR CONTROLLER BOARD	1-24
Replacement of the 100 BOARD	1-25
Replacement of the IDLER GEARS	1-27
Preventive Maintenance	1-28
Theory of Operation	2-1
Overview	2-2
Description	2-2
Operation of the BOARDS	2-6
Control of the DIVERter SOLENOIDS	2-6

Operation of the BIN SENSORS	2-7
Operation of the INTERLOCK BOARD for the TOP COVER	2-8
Operation of the SORTER Transport	2-9
Explanation of Error Codes	2-10
Diagnostics	3-1
Error Codes	3-1
Troubleshooting the BIN SENSORS	3-6
Troubleshooting the DIVERTERS	3-8
Component Locator	4-1
Component Lists	4-1
Diagrams	5-1
Illustrated Parts List	6-1
Miscellaneous Hardware, 1 of 2	6-2
Miscellaneous Hardware, 2 of 2	6-4
Bin, Top Cover, and Film Tray	6-6
Lower Transport Rollers, Diverters, and Idler Gears	6-8
Drive Motor and Drive Shaft	6-10
Encoder Wheel/Sprocket on the Processor	6-12
Modules	6-14
Main Module	6-16
Lead Module	6-18
Transport Module	6-20
Circuit Boards and Interlock Switch	6-22
Numerical Parts Index	7-1
Alphabetical Parts Index	8-1
Publication History	9-1

