

Section 10: Alphabetical Parts Index

Alphabetical Index

Part No.	Description	Figure No.
498941	Actuator	2-3
650876	Actuator	3-3, 3-4
556104	Adapter	6-6
911674	Adapter - Exhaust	5-1
499754	Adapter - Hose	6-7, 6-8
911678	Adapter - Plenum End	5-1
748501	Autotransformer	7-1
532164	Bar - Tie	3-29
227322	Battery	7-5
595426	Bearing	4-1
779119	Bearing	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-17, 3-18, 3-21, 3-24, 3-26, 3-30, 3-31, 3-32, 3-33
911684	Bearing	3-37
182399	Bearing	2-3
594273	Bearing	3-7, 3-16
650707	Bearing	3-3, 3-4
3B7301	Bearing - Thrust	3-30, 3-32
897205	Bearing - Thrust	4-1
532008	Bellows	6-4
914875	Bracket - Captive	3-29
963525	Bracket - Clip, Closed	8-4
963534	Bracket - Clip, Open	8-4
981893	Bracket - Detector Switch, Drive Side	7-3
981892	Bracket - Detector Switch, Nondrive Side	7-3
748023	Bracket - Dryer Thermistor/Thermostat	5-1
779451	Bracket - Entrance	8-3
474596	Bracket - Guide Shoe	3-10, 3-12, 3-13, 3-19, 3-21, 3-23, 3-27, 3-29, 3-38
594233	Bracket - Guide Shoe	3-3, 3-4, 3-12, 3-13, 3-21
8B7366	Bracket - Motor Mount	4-2
8B7356	Bracket - Plenum	5-1
911735	Bracket - Plenum	5-1
943422	Bracket - Sensor	3-38
955596	Bracket - Stop, Drive	3-34
955595	Bracket - Stop, Nondrive	3-34
943400	Bracket - Switch	5-1
5B6172	Bracket - TB1	2-4, 7-2
943068	Bracket - Thermowell	6-2
5B6892	Bracket - Tubing	3-24
943471	Bushing	3-16, 3-30
594240	Bushing	3-9, 3-18
594255	Bushing	3-7
911725	Bushing - Idler	3-23, 3-27
918094	Button - Replenishment Calibration Switch Assembly	7-1
943392	Cable - Printer Interface	7-2

Alphabetical Index

Part No.	Description	Figure No.
943357	Cable Assembly	3-38
544645	Cap - Fixer Recirculation	6-6
477506	Cap - Fuse Holder	7-4
943111	Caster	8-1
914737	Chain	3-32
943393	Chain - Drive	4-1, 4-2
943078	Chain - Ladder	3-30
779334	Chain - Roller	3-7, 3-9, 3-16, 3-18
981759	Circuit Board - Microprocessor, 500	7-4, 7-5
943371	Circuit Breaker	7-2
531927	Clamp	5-1
246800	Clamp - Hose	6-7, 6-8
246801	Clamp - Hose	6-7, 6-8, 6-9
246802	Clamp - Hose	6-7, 6-8
246805	Clamp - Hose	6-9
246808	Clamp - Hose	6-7, 6-8
5B6750	Clip - Wash Tank	6-9, 8-3
785462	Coil - 10 A	7-4
943435	Coil - 4 A	7-4
563378	Connector	7-4
616373	Connector	7-4
911400	Connector	7-4
918084	Connector	7-4
594782	Connector - Panel	6-6
943700	Coupling	6-9
8B7205	Cover	8-3
8B7206	Cover	8-3
5B6883	Cover - Autotransformer	2-4, 7-1
943415	Cover - Circuit Breaker	2-4
981296	Cover - Dryer Chain	3-34
5B6849	Cover - EMI Filter	2-4
613122	Cover - Evaporation	2-4
943421	Cover - Exit Assembly	3-35
1C4215	Cover - Motor	4-2
914706	Cover - Plenum Assembly	5-1
5B6884	Cover - Recirculation Pump	2-4
943112	Cover - Top	2-3
5B6487	Cover - Wet Section	2-4
8B7357	Cover - Wet Section	2-4
594838	Cup - Displacement	6-4
479821	Cylinder - Graduated	8-2
534770	Deflector - Air Tube	3-29
911692	Deflector - Rack	3-9
748640	Detector Crossover Assembly	3-2
918943	Detector Crossover Assembly	3-1
990339	Developer Rack Assembly	3-1, 3-5
990338	Developer/Fixer Crossover Assembly	3-1, 3-11
943701	Disconnect - Quick	6-9

Alphabetical Index

Part No.	Description	Figure No.
963548	Dryer - Front Cover	3-34
748638	Dryer Blower Assembly	5-1
8B7212	Dryer Plenum Assembly	3-34
943662	Dryer Plenum Assembly	3-34
8B7369	Dryer Rack Assembly	3-1, 3-28
192904	E-Ring	4-1
651107	E-Ring	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-17, 3-18, 3-21, 3-30, 3-31, 3-32, 3-33, 3-37
5B6618	EEPROM - Main	7-5
520390	Elbow	6-4
240733	Elbow - Exhaust	5-1
943412	Entrance Guide Shoe Assembly	8-3
990341	Exit Rack Assembly	3-1, 3-36
779453	Fastener	5-1, 8-3
914800	Filter	7-4
943376	Filter	7-4
943379	Filter	7-4
943442	Filter - Cartridge, Developer	6-5
914596	Filter - EMI Line	7-2
5B6156	Fitting	6-1
779379	Fitting - Bulkhead, 1-in.	6-6
1C7113	Fitting - Bulkhead, 3/8-in.	6-6, 6-7, 6-8
1C7112	Fitting - Bulkhead, 5/8-in.	6-6
478510	Fitting - Elbow	6-2
486480	Fitting - Elbow	6-7
493674	Fitting - Elbow	6-7, 6-8
180281	Fitting - T	6-7
981297	Fixer Rack Assembly	3-1, 3-14
918945	Fixer/Wash Crossover Assembly	3-1, 3-20
990332	Foot - Leveling	8-1
379381	Fuse - 0.25 A	7-4
273691	Fuse - 2.5 A	7-4
139941	Fuse - 5 A 250 Volt	7-4
597341	Fuse - 8 A	7-4
594535	Gasket	6-9
963528	Gasket - Feed Side Panel	2-1
544070	Gear	3-32
550774	Gear	3-7, 3-16, 3-30, 3-32
5B6570	Gear	3-37
5B6591	Gear	3-24, 3-26
779028	Gear	3-23, 3-24, 3-26, 3-27
911663	Gear	3-17, 3-31
911664	Gear	3-31, 3-32, 3-33
594241	Gear	3-9, 3-18
594254	Gear	3-7, 3-16, 3-17
550781	Gear - Drive, Crossover	3-3, 3-12, 3-21
594291	Gear - Gudgeon, Compound	3-8, 3-17

Alphabetical Index

Part No.	Description	Figure No.
594297	Gear - Idler	3-7
838999	Gear - Idler	3-16
532124	Gear - Snap-In	3-33
594248	Gear - Snap-In	3-8, 3-17, 3-33
594251	Gear - Snap-In	3-8
748955	Gear - Worm, Left	4-1
748956	Gear - Worm, Right	4-1
8B7122	Guard - Splash	3-25
918947	Guard - Splash	8-2
943469	Gudgeon - Snap-In	3-33
914724	Heat Exchanger	6-1
748511	Heater - Dryer	5-1
696165	Heater - Solution	6-2
943366	Holder - Fuse	7-4
943390	Hose - Air	5-1
1C4385	Hose - Yoke	3-23
914911	Housing - Entrance Detector	8-3
8B7213	Housing - Heater	5-1
418700	Housing - Inner	6-3
472605	Housing - Left Side	6-3
779458	Housing - Level Sensor, Developer	7-1
779473	Housing - Level Sensor, Fixer	7-1
472606	Housing - Right Side	6-3
418701	Housing and Impeller Assembly	6-3
609804	Idler	3-30
594253	Idler - Chain	3-9, 3-18
474362	Impeller	6-3
779401	Insulator	7-2
292888	Jack - ESD, Ground	7-4
943058	Label - Locking, Exit Rack	3-35
943387	Latch - Cover	2-3
607793	Locator	6-2
981894	Locator	3-9
598808	Lug - Ground	7-2
473926	Magnet	6-3
779330	Mandrel - Developer, Red	6-5
914719	Mandrel - Fixer, Blue	6-5
5B6585	Manifold - Water	3-23, 3-27
943403	Mask - Circuit Breaker	7-2
943105	Motor - Drive	4-2
5B6632	Mount - Bearing	4-1
990021	Mount - Bearing, Dryer End	4-1
911731	Mount - Bearing, Feed End	4-1
520391	Nut	6-4
853080	Nut	3-7, 3-9, 3-16, 3-18, 3-30
779376	Nut - Jam	6-6
779377	Nut - Jam	6-6
779378	Nut - Jam	6-6, 6-7, 6-8

Alphabetical Index

Part No.	Description	Figure No.
853155	Nut - Jam	8-1
173865	Nut - Lock, 3/4-in.	6-6
911683	Nut - Special	3-38
472756	Nut - Special D, Long	3-3, 3-12, 3-21
472755	Nut - Special N-D, Short	3-4, 3-13
144097	Nut - Wing	6-3
740639	Nut - Wing	6-5
183851	O-Ring	3-24, 3-26
463363	O-Ring	6-3
520388	O-Ring	6-4
535639	O-Ring	6-4
740721	O-Ring	6-5
532378	O-Ring - Seal	6-1
459576	Orifice	6-8
914732	Orifice - 0.125 in.	6-7
914731	Orifice - 0.250 in.	6-7
5B6607	PROM - Bootstrap	7-5
963532	Panel - Drive Side	2-1
963531	Panel - Dryer Side	2-2
963529	Panel - Feed Side	2-1
963530	Panel - Nondrive Side	2-2
502464	Pin	3-3, 3-7, 3-9, 3-12, 3-16, 3-17, 3-18, 3-21, 3-24, 3-26, 3-30, 3-31, 3-32, 3-33
544081	Pin	3-32
853000	Pin	4-1
914898	Pin - Dowel	4-1
943419	Pin - Hinge	2-3
943120	Plate - Hinge, Drive Side	2-3
943119	Plate - Hinge, Nondrive Side	2-3
288235	Plate - Tap	2-3, 7-3
911675	Plenum - Air Return	5-1
536858	Plug	6-6
5B6634	Plug	3-30
541891	Plug - Thermowell	6-2
955745	Power Supply - DC	7-4
779459	Probe - Level Sensor	7-1
1C4593	Recirculation Pump Assembly	6-3
748131	Relay	7-4
655290	Relay - Solid State, 20 A	7-4
1C4594	Replenishment Pump Assembly	6-4
5B6899	Reservoir - Wash	6-9
990009	Resistor Pack	7-4
594103	Retainer - Bearing	4-1
968277	Rib	2-3
472592	Rocker - Bearing	3-3, 3-4
458219	Rod - Tie	3-10, 3-19, 3-23, 3-24, 3-27
458394	Rod - Tie	3-37, 3-38

Alphabetical Index

Part No.	Description	Figure No.
458170	Rod - Tie	3-2, 3-3, 3-4, 3-12, 3-13, 3-21
490109	Roller - Detector "A"	3-2
490108	Roller - Detector "B"	3-2
246679	Roller Assembly	3-36
246979	Roller Assembly	3-15, 3-16, 3-36, 3-37
458949	Roller Assembly	3-36, 3-37
587329	Roller Assembly	3-28, 3-33
594237	Roller Assembly	3-6, 3-7, 3-13, 3-15, 3-16, 3-17, 3-36, 3-37
5B6568	Roller Assembly	3-24, 3-25
5B6590	Roller Assembly	3-22, 3-24, 3-25, 3-26
8B6568	Roller Assembly	3-22, 3-26
911660	Roller Assembly	3-28, 3-31, 3-32, 3-33, 3-36, 3-37
911662	Roller Assembly	3-28, 3-31
990014	Roller Assembly	3-36, 3-37
990015	Roller Assembly	3-36, 3-37
489693	Roller Assembly	3-6, 3-8, 3-15, 3-17
562330	Roller Assembly	3-3, 3-4
594243	Roller Assembly	3-6, 3-9
594244	Roller Assembly	3-15, 3-18
594288	Roller Assembly	3-6, 3-8, 3-15, 3-17
748875	Roller Assembly	3-6, 3-9, 3-15, 3-18
911661	Roller Assembly	3-6, 3-8
968796	Roller Assembly	3-6, 3-7
981284	Roller Assembly	3-15, 3-17
594271	Roller Assembly - Rewet	3-6, 3-7, 3-15, 3-16
8B7110	Roller Assembly - Squeegee, Drive	3-28, 3-30
8B7111	Roller Assembly - Squeegee, Driven	3-28, 3-30
914744	Screen - Heater	5-1
165626	Screw	3-27
167737	Screw	5-1
187235	Screw	2-4, 4-1, 6-2, 7-2, 8-4
188840	Screw	8-1
191097	Screw	7-2
191107	Screw	5-1
353141	Screw	3-30
3B7276	Screw	5-1
3B7398	Screw	3-38
490097	Screw	3-24, 3-26
493422	Screw	3-35
544194	Screw	3-3, 3-4, 7-1
544267	Screw	3-23, 3-27
556032	Screw	2-3, 5-1
562201	Screw	8-3
566107	Screw	5-1
575821	Screw	3-3, 3-4, 3-34, 7-3

Alphabetical Index

Part No.	Description	Figure No.
5B6316	Screw	3-3, 3-4, 3-10, 3-12, 3-13, 3-19, 3-21, 3-29, 3-38
619284	Screw	2-3, 4-1, 4-2, 5-1, 6-2, 7-1
852522	Screw	3-23, 7-3, 8-3
852558	Screw	4-2
852682	Screw	3-3, 3-4, 3-23, 3-24, 3-30, 3-37, 3-38, 5-1, 8-3
852807	Screw	3-9, 3-10, 3-19, 3-23, 3-27
852811	Screw	3-29, 3-34
852887	Screw	7-2
852945	Screw	3-34
852946	Screw	3-38, 6-3
852982	Screw	7-2
853165	Screw	5-1
544132	Screw	3-7
594320	Screw	3-9, 3-18
852806	Screw	2-3
852959	Screw	3-16
853141	Screw	3-9, 3-18
963537	Screw - Leveling	8-1
1C7237	Screw - Shoulder	7-1
5B6648	Screw - Shoulder	3-37
5B6808	Screw - Shoulder	3-23, 3-27
990010	Screw - Shoulder	3-31
981278	Seismic Bracket Kit	8-1
1C7366	Shaft	3-24, 3-25, 3-26
5B6587	Shaft	3-24, 3-26
5B6588	Shaft	3-24, 3-26
5B6817	Shaft	3-24, 3-26
748021	Shaft	3-31
911653	Shaft	3-37
981299	Shaft	3-28, 3-32
458175	Shaft	3-3, 3-4
594230	Shaft	3-12, 3-13, 3-21
594236	Shaft	3-9, 3-18
594242	Shaft	3-9, 3-18
943468	Shaft	3-17
943473	Shaft	3-7, 3-16
990022	Shaft	3-7, 3-16
1C4951	Shaft - Drive	3-28, 3-30, 3-32
981298	Shaft - Drive	4-1
594229	Shaft - Drive Side	3-3, 3-4, 3-12, 3-13, 3-21
748022	Shaft - Idle	3-33
562650	Shield	4-1
8B6662	Shim	4-1
911732	Shim	4-1
458953	Shoe - Guide	3-2, 3-3, 3-4
562389	Shoe - Guide	3-12, 3-13, 3-21

Alphabetical Index

Part No.	Description	Figure No.
562765	Shoe - Guide	3-10, 3-19
5B6001	Shoe - Guide	3-21
8B7377	Shoe - Guide	3-23, 3-27
911748	Shoe - Guide	3-38
911749	Shoe - Guide	3-38
914703	Shoe - Guide	3-10, 3-19
914704	Shoe - Guide	3-29
990017	Shoe - Guide	3-12, 3-13
779435	Sideplate - Crossover	3-12, 3-13, 3-21
5B6548	Sideplate - Detector Crossover, Drive	3-3
5B6549	Sideplate - Detector Crossover, Nondrive	3-4
779432	Sideplate - Developer Rack, Drive	3-7, 3-8
779431	Sideplate - Developer Rack, Nondrive	3-7, 3-8
8B6560	Sideplate - Dryer Rack, Drive	3-38
981294	Sideplate - Dryer Rack, Drive	3-30
8B6561	Sideplate - Dryer Rack, Nondrive	3-38
981293	Sideplate - Dryer Rack, Nondrive	3-30
943467	Sideplate - Fixer Rack, Drive Side	3-16
943466	Sideplate - Fixer Rack, Nondrive Side	3-16
8B7353	Sideplate - Wash Rack, Drive	3-23, 3-24, 3-26, 3-27
8B7354	Sideplate - Wash Rack, Nondrive	3-23, 3-24, 3-26, 3-27
594252	Sleeve	3-9, 3-18
532108	Sleeve - Blower, Outlet	5-1
779344	Solenoid - Cooling	6-7
963545	Solenoid - Water	6-9
200130	Spacer	7-4
5B6589	Spacer	3-24, 3-26
953828	Spacer	3-24, 3-26
8B7203	Spacer - Thermostat	5-1
914915	Spindle - Cover	2-3
467843	Spring	3-7, 3-16
562500	Spring	3-9, 3-18
562609	Spring - Air Tube	3-29
1C7107	Spring - Extension	3-24, 3-26, 3-37
1C7106	Spring - Extension	3-12, 3-13, 3-17, 3-21, 3-30
454454	Sprocket	4-2
8B7109	Sprocket	3-30, 3-32
914721	Sprocket	4-1
594261	Sprocket	3-7, 3-16
613246	Sprocket	3-9, 3-18
489997	Standoff - Pivot	3-3, 3-4
5B6592	Stiffener - Tank Wall	8-3
943389	Strain Relief	3-38
472261	Strainer Assembly	8-2
981288	Stud - Ball	8-4
562228	Stud - Snap-In	3-3, 3-4, 3-8, 3-17, 3-31, 3-33
474180	Support	3-3, 3-4
943375	Switch - Air Flow	5-1

Alphabetical Index

Part No.	Description	Figure No.
914599	Switch - Entrance Detector	2-3, 7-3
943397	Switch - Exit Sensor	3-38
955719	Switch - Replenishment Calibration	7-1
191611	Terminal Block	7-2
241883	Terminal Block	7-4
243572	Terminal Block	7-4
779400	Terminal Block	7-2
911433	Thermistor - Dryer	5-1
911432	Thermistor - Solution	6-2
955741	Thermostat - Dryer Overtemperature	5-1
8B7080	Thermowell	6-2
182590	Tie	6-9
459432	Tray - Drip	8-2
1C7229	Trough - Crossover, Developer/Fixer	3-11
914920	Trough - Crossover, Developer/Fixer	3-11
1C7230	Trough - Crossover, Fixer/Wash	3-20
914922	Trough - Crossover, Fixer/Wash	3-20
240101	Tube - Air, Metal	3-28, 3-29
914921	Tube - Air, Snouted	3-28, 3-29
1C4384	Tube - Yoke Supply	3-23
5B6152	Tubing - Formed	6-7
5B6153	Tubing - Formed	6-7
8B6660	Tubing - Formed	6-7, 6-8
8B6661	Tubing - Formed	6-7, 6-8
943084	Tubing - Formed	6-7, 6-8
943085	Tubing - Formed	6-7, 6-8
943086	Tubing - Formed	6-7
943087	Tubing - Formed	6-8
943088	Tubing - Formed	6-7, 6-8
943089	Tubing - Formed	6-7, 6-8
943090	Tubing - Formed	6-7, 6-8
943091	Tubing - Formed	6-7, 6-8
943092	Tubing - Formed	6-9
943093	Tubing - Formed	6-9
943094	Tubing - Formed	6-9
943095	Tubing - Formed	6-8
943096	Tubing - Formed	6-7
943097	Tubing - Formed	6-7
943098	Tubing - Formed	6-7
943099	Tubing - Formed	6-7
943102	Tubing - Formed	6-7, 6-8
943402	Tubing - Formed	6-9
8B7123	Tubing - Wash Reservoir	6-9
1C4398	Tubing Assembly	3-24
609817	Valve	6-4
779359	Valve - Drain, Blue	6-8
779468	Valve - Drain, Red	6-7
1C4968	Valve - Flow Control	6-9

Alphabetical Index

Part No.	Description	Figure No.
5B7730	Valve - Flow Control	6-9
963541	Valve - Flow Control	6-9
535638	Valve Body	6-4
943377	Varistor	7-4
943378	Varistor	7-4
5B6575	Wash Rack Assembly	3-25
5B6890	Wash Rack Assembly	3-1, 3-22
165627	Washer	3-3, 3-4, 7-3, 8-3
483051	Washer	6-6
493505	Washer	6-3
575822	Washer	2-3, 3-3, 3-4, 5-1, 7-2, 7-3
594534	Washer	6-9
748957	Washer	4-1
852611	Washer	3-3, 3-4, 3-7, 3-9, 3-16, 3-18, 3-24, 3-26, 3-27, 3-30, 5-1
852616	Washer	2-3, 2-4, 3-34, 4-2, 5-1, 6-2, 7-1, 7-2, 8-4
852799	Washer	4-1, 5-1
557822	Washer	2-3
562226	Washer	3-7, 3-9, 3-16, 3-18
459943	Washer - Identification, Developer	3-10
459946	Washer - Identification, Developer/Fixer Crossover	3-12
459944	Washer - Identification, Fixer	3-19
459947	Washer - Identification, Fixer/Wash Crossover	3-21
187213	Washer - Lock	7-3, 8-3
191098	Washer - Lock	2-3, 5-1, 7-2, 7-3
852961	Washer - Lock	2-3, 2-4, 4-1, 4-2, 5-1, 6-2, 7-1, 8-1, 8-4
853087	Washer - Lock	3-3, 3-4, 3-7, 3-9, 3-16, 3-18, 3-30, 3-37, 3-38
853100	Washer - Lock	5-1
187283	Washer - Lock	3-3, 3-4
853096	Washer - Lock	3-3, 3-4
489174	Washer - Rubber, 3/8-in.	6-6
1C4721	Washer - Rubber, 5/8-in.	6-6
748043	Washer - Sealling	7-1
539180	Washer - Star	3-24
418775	Washer - Thrust	3-3, 3-4, 3-7, 3-9, 3-12, 3-13, 3-16, 3-18, 3-21, 3-24, 3-26, 3-30, 3-31, 3-32, 3-37
619512	Washer - Thrust	3-30, 3-32
1C7399	Yoke and Pin Assembly	3-23