

Section 8: Miscellaneous

Table of Contents

Description	Page
Miscellaneous	8-1
Figure 8-1 Leveling Feet	8-2
Figure 8-2 Accessories	8-3
Figure 8-3 Miscellaneous Tank Assembly	8-4
Figure 8-4 Electrical Box Latch	8-6

Figure 8-1 Leveling Feet




H127_0101DCA
H127_0101DA

Figure 8-1

Item	Part No.	Description
1	853155	Nut - Jam
2	963537	Screw - Leveling
3	990332	Foot - Leveling
4	943111	Caster
5	852961	Washer - Lock
6	188840	Screw
7	981278	Seismic Bracket Kit

Figure 8-2 Accessories




H127_0102DCA
H127_0102DA

Figure 8-2

Item	Part No.	Description
1	472261	Strainer Assembly
2	479821	Cylinder - Graduated
3	459432	Tray - Drip
4	918947	Guard - Splash

Figure 8-3 Miscellaneous Tank Assembly



H127_0224ECA
H127_0224EA

Figure 8–3

Item	Part No.	Description	Notes
1	852522	Screw	
2	187213	Washer - Lock	
3	165627	Washer	
4	914911	Housing - Entrance Detector	
5	779451	Bracket - Entrance	
6	943412	Entrance Guide Shoe Assembly	
7	5B6750	Clip - Wash Tank	
8	5B6592	Stiffener - Tank Wall	
9	779453	Fastener	For 180 LP Serial No. 3000 and above, and 180 LPS Serial No. 13,000 and above.
10	8B7205	Cover	For 180 LP Serial No. 3000 and above, and 180 LPS Serial No. 13,000 and above.
11	562201	Screw	For 180 LP Serial No. 3000 and above, and 180 LPS Serial No. 13,000 and above.
12	852682	Screw	For 180 LP Serial No. 3000 and above, and 180 LPS Serial No. 13,000 and above.
13	8B7206	Cover	For 180 LP Serial No. 3000 and above, and 180 LPS Serial No. 13,000 and above.

Figure 8-4 Electrical Box Latch


H127_0130DCA
H127_0130da

Figure 8-4

Item	Part No.	Description
1	852616	Washer
2	852961	Washer - Lock
3	187235	Screw
4	963525	Bracket - Clip, Closed
5	981288	Stud - Ball
6	963534	Bracket - Clip, Open