




ADJUSTMENTS AND REPLACEMENTS for the *Kodak X-Omat 5000* RA PROCESSOR



H148_0004GA

PLEASE NOTE The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.

Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from any use of this information, even if loss or damage is caused by Kodak's negligence or other fault.



Warning

To avoid hazardous conditions, keep floors and floor coverings around your *Kodak X-Omat* 5000 RA Processor and associated drains clean and dry at all times. Any accumulation of fluids from mixing tanks, drain lines, etc., should be cleaned up immediately. In the event of an accumulation of liquid due to backup, overflow, or other malfunctions of the drain associated with your *Kodak X-Omat* 5000 RA Processor, call a plumber or other contractor to correct any problem with the drain. Kodak accepts no responsibility or liability whatsoever for the serviceability of any drain connected to or associated with a *Kodak X-Omat* Processor. Such drains are the sole responsibility of the customer.



Important

This manual is intended for use by qualified service personnel only.

This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.



Table of Contents

Description	Page
Service Overview	1-1
Special Tools	1-2
Electrostatic Discharge	1-3
Overview	1-3
Preventive Measures	1-3
Common Procedures for Service Preparation	1-3
De-energizing and Energizing the PROCESSOR	1-4
Disabling the COVER INTERLOCK SWITCHES	1-5
Placing a CLAMP on a HOSE	1-5
Identifying the RACKS and CROSSOVERS	1-6
Removing the RACKS	1-7
Installing the RACKS	1-9
Draining the TANKS	1-10
Filling the TANKS	1-11
Identifying and Removing the COVERS and PANELS	1-12
Identifying the Connections on the COMPONENT PLATE	1-14
Routing of the CABLE HARNESS	1-14
Removing the ELECTRICAL BOX	1-15
RACKS and CROSSOVERS	2-1
Overview of Transport	2-2
Adjusting the FEED TRAY	2-3
Aligning the FILM GUIDE	2-3
Adjusting the Squareness of the RACKS	2-5
Removing the WASH TROUGHS from the CROSSOVERS	2-6
Adjusting the Squareness of the CROSSOVERS	2-7
Adjusting the CHAIN	2-8

Installing the CHAIN	2-9
Removing the DRIVE ROLLER from the RACK	2-10
Disassembling the TURNAROUND	2-12
Main Drive	3-1
Aligning the SPROCKET	3-2
Adjusting the Tension of the MOTOR DRIVE CHAIN	3-2
Lubricating the CHAIN	3-3
Removing the DC DRIVE MOTOR	3-3
Removing the DRIVE SHAFT	3-6
Removing the BEARINGS	3-7
DRYER	4-1
Removing the DRYER HEATER, THERMOSTAT, and BLOWER	4-2
Removing the DRYER PLENUM and DRYER THERMISTOR	4-4
Removing a DRYER TRANSPORT ROLLER PULLEY	4-5
Removing the DRYER DRIVE PULLEY	4-6
Removing the DRYER DRIVE BELT	4-6
Adjusting the DRYER DRIVE BELT	4-8
Removing a DRYER ROLLER SUPPORT	4-9
Removing the TURNAROUND DRIVE ROLLER	4-10
Removing the DRYER EXHAUST FAN	4-11
Plumbing	5-1
Removing the RECIRCULATION PUMP B5	5-2
Removing the IMPELLER or the IMPELLER HOUSING	5-3
Removing the REPLENISHMENT PUMPS: B3 and B4	5-4
Removing the HEATER for the Developer or Fixer	5-6
Removing the THERMISTOR for the Developer or Fixer	5-8
Removing the DEVELOPER FILTER CANISTER	5-9
Removing the DEVELOPER HEAT EXCHANGER	5-10
Removing the DRAIN VALVES for the Developer and Fixer	5-11
Removing the REPLENISHMENT QUICK DISCONNECT VALVES	5-13
Removing the WASH WATER SOLENOID L1	5-14
Removing the COOLING/DRAIN SOLENOID L2	5-15
Removing the TANK	5-16
Electrical	6-1
Adjusting the ACTUATORS and the ENTRANCE DETECTOR SWITCH	6-2
Removing the FAN	6-5
Removing CIRCUIT BREAKER CB1	6-6
Removing SAFELIGHT RECEPTACLE J101	6-7
Removing the 2000 INTERFACE BOARD	6-8
Adjusting the Brightness of the CONTROL PANEL	6-9
Removing the 5000 MICROPROCESSOR BOARD	6-10
Downloading the Operating Software	6-12
Bypassing or Resetting the Access Code	6-13
Removing the 6000 FILM ACCUMULATOR BOARD	6-14
Removing the 7000 INTERLOCK and the MOTOR CONTROLLER BOARDS	6-16
Removing the 3000 BOARD, the LCD, and the DISPLAY PANEL	6-18
Enabling and Adjusting the ROOMLIGHT SENSOR on the 3000 BOARD	6-22
Removing the BUCK/BOOST TRANSFORMER T1	6-23
Removing an EMI LINE FILTER	6-24
Removing the QUAD POWER SUPPLY PS1	6-25
Removing the +5 V DC and the +24 V DC POWER SUPPLIES: PS2 and PS3	6-27
Adjusting the 5 V DC POWER SUPPLY PS2	6-29
Publication History	7-1

