

Section 4: Dryer

Figure 4-1 Dryer



H166_0044ECA
H166_0044EA

Figure 4-1 Dryer

Item	Part No.	Description	Notes
1	1C7235	Plenum - Heater	Does not include item 30. Includes item 3.
2	1C7218	Heater - 3000 Watt	
3	8B6574	Thermal Cut-off	
4	575820	Screw	
5	187213	Washer - Lock	
6	165627	Washer	
7	1C7249	Grommet	
8	1C7248	Shield - Heat	
9	619284	Screw	
10	852961	Washer - Lock	
11	852799	Washer	
12	1C7226	Sleeve - Blower	
13	9B8251	Blower	Includes item 14.
14	1C7232	Bracket - Blower	
15	1C7264	Thermistor - Dryer	
16	562201	Screw	
17	246875	Holder - Tie	
18	275372	Tie	
19	1C7243	Adapter - Exhaust	
20	852885	Screw	
21	9B8258	Thermostat - Overtemperature	
22	191097	Screw	
23	531927	Clamp	
24	480820	Screw	
25	5B6595	Duct - Exhaust	
26	5B6562	Hose - Short	
27	853100	Washer - Lock	
28	852611	Washer	
29	853080	Nut	
30	2B0415	Label - Warning	
31	562213	Holder - Tie	
32	182590	Tie	
33	911677	Hose - Long	
34	911737	Bracket - Exhaust	Not stocked, Special Order
35	9219043	Adapter - Exhaust	
36	911679	Adapter - Exhaust	
37	911680	Hose	
38	911674	Adapter - Exhaust	

