



**SERVICE MANUAL**  
for the  
***Kodak X-Omatic* IDENTIFICATION CAMERA**  
**MODELS 4, 4L, and 4SL**

**PLEASE NOTE**

The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.

Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from any use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.



## Table of Contents

Description	Page
<a href="#">Electrostatic Discharge</a> .....	1-1
<a href="#">Description and Specifications</a> .....	2-1
<a href="#">Description</a> .....	2-1
<a href="#">Specifications</a> .....	2-1
<a href="#">Space Requirements</a> .....	2-1
<a href="#">Environmental Requirements</a> .....	2-1
<a href="#">Cassettes</a> .....	2-2
<a href="#">Power Requirements</a> .....	2-2
<a href="#">Sequence of Operation</a> .....	3-1
<a href="#">Normal Operation</a> .....	3-1
<a href="#">Diagrams</a> .....	4-1
<a href="#">Block diagram for the Identification Camera, Models 4, 4L, and 4SL</a> .....	4-1
<a href="#">Schematic diagram for the Identification Camera, Models 4, 4L, and 4SL</a> .....	4-1
<a href="#">Wiring diagram for the P/A and A/P LCD Lamp Sensor</a> .....	4-1
<a href="#">Wiring diagram for the LCD Main</a> .....	4-1
<a href="#">Diagnostic Procedures</a> .....	5-1
<a href="#">LED Indicator Meanings</a> .....	5-1
<a href="#">Error Code Table</a> .....	5-2
<a href="#">Electrical Adjustments</a> .....	6-1
<a href="#">COVER Removal Procedure</a> .....	6-1
<a href="#">Selecting the Correct Voltage</a> .....	6-3
<a href="#">Setting the Date Format</a> .....	6-4
<a href="#">Setting the Time Format</a> .....	6-5
<a href="#">Setting the Date and Time</a> .....	6-6
<a href="#">Adjusting POTENTIOMETERS</a> .....	6-8
<a href="#">Adjusting POTENTIOMETER VR1</a> .....	6-9
<a href="#">Adjusting POTENTIOMETER VR2</a> .....	6-11
<a href="#">Adjusting POTENTIOMETER VR3</a> .....	6-12
<a href="#">Adjusting POTENTIOMETER VR4</a> .....	6-13
<a href="#">Adjusting POTENTIOMETER VR5</a> .....	6-14
<a href="#">Mechanical Adjustments</a> .....	7-1
<a href="#">A-P PLATE Removal Procedure</a> .....	7-1
<a href="#">UPPER HOUSING ASSEMBLY Removal Procedure</a> .....	7-2
<a href="#">Adjusting the LENSES</a> .....	7-5
<a href="#">Adjusting the A-P MIRROR SWITCH SW1 and P-A MIRROR SWITCH SW2</a> .....	7-7
<a href="#">Adjusting the C-1 Lens Switch SW7 and C-1N Lens Switch SW8</a> .....	7-9
<a href="#">Adjusting the ACTUATOR HOME SWITCH SW3</a> .....	7-11
<a href="#">Adjusting the ACTUATOR EXTENDED SWITCH SW4</a> .....	7-13

---

<a href="#">Adjusting the Depth of the CARRIAGE Z-PIN</a> .....	7-14
<a href="#">Adjusting the MIRROR Tilt</a> .....	7-15
<a href="#">Electrical Replacements</a> .....	8-1
<a href="#">Replacement of the POWER SWITCH</a> .....	8-1
<a href="#">Replacement of the A-P CIRCUIT BOARD</a> <a href="#">CIRCUIT BOARD</a> .....	8-2
<a href="#">Replacement of the P-A CIRCUIT BOARD</a> .....	8-3
<a href="#">Replacement of the TRANSFORMER</a> .....	8-5
<a href="#">Replacement of the CPU BOARD</a> .....	8-7
<a href="#">Replacement of the LCD DISPLAY BOARD</a> .....	8-8
<a href="#">Mechanical Replacements</a> .....	9-1
<a href="#">Replacement of the ACTUATOR ASSEMBLY</a> .....	9-1
<a href="#">Replacement of the ACTUATOR SWITCH ASSEMBLY</a> .....	9-2
<a href="#">Replacement of the A-P and P-A LAMPS</a> .....	9-3
<a href="#">Replacement of the MAIN EXPOSURE LAMPS</a> .....	9-4
<a href="#">Replacement of the LENS DRIVE MOTOR</a> .....	9-5
<a href="#">Replacement of the MIRROR DRIVE MOTOR</a> .....	9-6
<a href="#">Replacement of the MAIN EXPOSURE LAMP SOCKETS</a> .....	9-8
<a href="#">Replacement of the MIRROR ASSEMBLY</a> .....	9-9
<a href="#">Replacement of the LENS TRAVELLER ASSEMBLY</a> .....	9-10
<a href="#">Replacement of the LENSES</a> .....	9-12
<a href="#">Replacement of the LENS POSITION SWITCHES</a> .....	9-13
<a href="#">Replacement of the DRIVE MOTOR and the GEARBOX</a> .....	9-14
<a href="#">Replacement of the MIRROR POSITION SWITCHES</a> .....	9-15
<a href="#">Replacement of the X and Y POSITION SWITCHES</a> .....	9-16
<a href="#">Illustrated Parts List</a> .....	10-1
<a href="#">Numerical Index</a> .....	11-1
<a href="#">Alphabetic Parts Index</a> .....	12-1
<a href="#">Publication History</a> .....	13-1

