

Section 10: Illustrated Parts List

Figure 10-1 Covers, Buttons, and Display area




H139_0039ECA
H139_0039EA

Figure 10–1

Item	Part No.	Description	Qty.	Notes
1	990824	Cover - Top	1	
2	2B6419	Screw - Pan head, 4 x 12 mm	2	
3	990822	Cover - Card positioning, Models 4L and 4SL	1	
4	990821	Display - LCD	1	
5	732335	Screw - Pan head, 4 x 8 mm	4	
6	2B6325	Cover - LCD	1	
7	990820	Cable - Ribbon, display	1	
8	2B6326	Screw	3	
9	2B6359	Plate - Reinforcement	1	
10	2B6328	Button - Lens	1	
11	2B6329	Button - Date, density or clock	7	
12	2B6336	Stopper - Button	7	
13	990823	Cover - Card positioning, Model 4	1	
14	8B6727	Strip - Derlin	1	

Figure 10-2 Circuit Board, Power Switch, and Power Cords




H139_0038ECA
H139_0038EA

Figure 10–2

Item	Part No.	Description	Qty.	Notes
1	990894	Plate - CPU circuit board	1	
2	2B6416	Screw - Pan head, 3 x 15 mm	4	
3	605777	Nut - M3	4	
4	732335	Screw - Pan head, 4 x 8 mm	6	
5	616289	Cord - Power, AC 100-120 V	1	
6	476324	Cord - Power, AC 220 V	1	
7	2B6358	Base	1	
8	990819	Foot	4	
9	755244	Screw - Pan head, 4 x 25 mm	4	
10	990818	Socket - Power switch	1	
11	2B6407	Screw - Flat head, 3 x 10 mm	2	
12	990817	Bracket - Power switch	1	
13	714284	Screw - Pan head, 4 x 6 mm	2	
14	990815	Window	1	
15	251212	Screw - Pan head, 3 x 8 mm	8	
16	990816	Switch - Power	1	
17	238304	Screw - Pan head, 3 x 6 mm	8	
18	990814	Bracket - Power switch	1	
19	990813	Rod - Actuator, power switch	1	
20	990812	Bracket - Actuator, power switch	2	
21	990810	Button - Power	1	
22	990811	Spring - Return, power switch actuator	1	
23	990808	Cover - Power switch	1	
24	2B6327	Shield - EMI	1	
25	990807	Finger - EMI	1	
26	990893	Board - CPU	1	

Figure 10-3 Lenses and Mirrors




H139_0040ECA
H139_0040EA

Figure 10-3

Item	Part No.	Description	Qty.	Notes
1	1C0065	Lens Assembly, Model 4 (not illustrated)	1	##Includes items 2 - 19, 21, and 27##
1	1C0060	Lens Assembly, Model 4L (illustrated)	1	##Includes items 2 - 19, 21, and 27##
1	8B7328	Lens Assembly, Model 4SL (not illustrated)	1	##Includes items 2 - 17, 21, and 27##
2	990831	Bracket - Lens alignment	1	
3	990832	Rod - Lens shift	2	
4	990833	Bracket - Lens stop	1	
5	990836	Linkage - Lens	1	
6	234905	Screw - Pan head, 2 x 5 mm	2	
7	2B6423	Screw - Pan head, 3 x 12 mm	2	
8	732335	Screw - Pan head, 4 x 8 mm	8	
9	990825	Bracket - Lens Motor	1	
10	990828	Wire - Lens linkage, Model 4 (not illustrated)	1	
10	1C0200	Wire - Lens linkage, Model 4L (illustrated)	1	
10	8B7325	Wire - Lens linkage, Model 4SL (not illustrated)	1	
11	990827	Nut	2	
12	2B6338	Star - Motor linkage	1	
13	283112	Screw - Pan head, 3 x 20 mm	6	
14	990861	Lens - C-1	1	
15	1C0058	Screw - 2 x 5 mm	2	
16	990826	Motor - Lens/Mirror	2	
17	990837	Plate, Switch actuator, Model 4 (not illustrated)	1	
17	1C0202	Plate, Switch actuator, Model 4L/4SL (illustrated)	1	
18	2B6340	Lens - C-1N (not used on 4SL)	1	
19	2B6341	Bracket - Lens, Models 4 and 4L (illustrated)	1	
19	8B7327	Bracket - Lens, Model 4SL (not illustrated)	1	
20	251212	Screw - Pan head, 3 x 8 mm	8	
21	2B6339	Bracket - Lens shift rod, Models 4 and 4L (illustrated)	1	
21	8B7326	Bracket - Lens shift rod, Model 4SL (not illustrated)	1	
22	990829	Cover - C-1N lens	1	
23	1C0205	Bracket - Lens switch B, Model 4L	1	
24	654373	Screw - Pan head, 2 x 10 mm	4	
25	990838	Microswitch	2	
26	256700	Screw - Pan head, 3 x 10 mm	2	
27	499222	Bolt - Cap, 3 x 10 mm	2	
28	990850	Bracket - Lens, Model 4 (not illustrated)	1	
28	1C0203	Bracket - Lens, Models 4L and 4SL (illustrated)	1	
29	990851	Mount - Mirror traveler	1	
30	990842	Bracket - C1-N In switch, Model 4L	1	
30	990842	Bracket - C1-N In switch, Models 4 and 4SL	2	

Figure 10-4 Lenses and Mirrors




H139_0040ECA
H139_0040EA

Figure 10–4

Item	Part No.	Description	Qty.	Notes
31	1C0055	Screw - Button, 5 x 12 mm	3	
32	2B6344	Bearing	3	
33	990855	Plate - Base, mirror	1	
34	990853	Actuator - Mirror switch	1	
35	731091	Bolt - Cap, 3 x 8 mm	4	
36	990856	Bracket - Adjustment, mirror	1	
37	990857	Mirror	1	
38	990858	Bracket - Mirror	1	
39	990827	Nut	1	
40	990852	Stiffener - Mirror bracket	1	
41	1C0063	Ring	1	
42	238304	Screw - Pan head, 3 x 6 mm	2	
43	990847	Wire - Mirror linkage	1	
44	990846	Star - Motor linkage	1	
45	990845	Bracket - Mirror motor	1	
46	990848	Switch - Mirror	2	
47	2B6416	Screw - Pan head, 3 x 15 mm	4	
48	1C0064	Mirror Assembly, Model 4 (not illustrated)	1	##Includes items 7, 8, 11, 16, 31 - 45##
48	1C0059	Mirror Assembly, Model 4L/4SL (illustrated)	1	##Includes items 7, 8, 11, 16, 31 - 45##
49	990849	Bracket - Mirror switch	2	

Figure 10-5 Lamps, Clock, Card Holder, and Housing parts




H139_0037ECA
H139_0037EA

Figure 10–5

Item	Part No.	Description	Qty.	Notes
1	1C0067	A-P Card Holder Assembly, Model 4	1	##Includes items 2, 3, 4, 5, 6##
1	1C0062	A-P Card Holder Assembly, Model 4L/4SL	1	##Includes items 2, 3, 4, 5, 6##
2	990869	Cable - A-P ribbon	1	
3	990874	LCD - IDK-13A	1	
4	324259	Screw - Pan head, 3 x 5 mm	8	
5	2B6352	Wire - Ground	1	
6	990868	Bulb - Clock	1	
7	2B6342	Wire - Ground	1	
8	990864	Holder - P-A card	1	
9	990868	Bulb - Clock	1	
10	990867	Cable - P-A ribbon	1	
11	1C0066	P-A Card Holder Assembly, Model 4	1	##Includes items 4, 7, 8, 9, 10##
11	1C0061	P-A Card Holder Assembly, Model 4L/4SL	1	##Includes items. 4, 7, 8, 9, 10##
12	256700	Screw - Pan head, 3 x 10 mm	10	
13	990863	Holder - P-A card	1	
14	990834	Cover - Back shield, upper housing	1	
15	732335	Screw - Pan head, 4 x 8 mm	12	
16	238304	Screw - Pan head, 3 x 6 mm	12	
17	990830	Cover - Front shield, upper housing	1	
18	990835	Housing - Upper shield, Model 4 (not illustrated)	1	
18	1C0201	Housing - Upper shield, Model 4L/4SL (illustrated)	1	
19	990844	Bracket A - Lamp	1	
20	990841	Socket - Lamp	2	
21	990840	Lamp	2	
22	2B6337	Bracket B - Lamp	1	
23	2B6349	Bracket B - Card holder	1	
24	2B6411	Screw - Pan head, 4 x 4 mm	4	
25	2B6350	Bracket A - Card holder	1	
26	2B6351	Bracket - Card holder, Model 4 (not illustrated)	1	
26	1C0204	Bracket - Card holder, Model 4L/4SL (illustrated)	1	
27	2B6348	Holder - A-P card	1	
28	2B6345	Roller - Card	1	
29	2B6346	Bracket - Card roller	2	
30	2B6347	Spring - Card roller	2	

Figure 10-6 Actuator, Switches, Fuses, and Transformer




H139_0036ECA
H139_0036EA

Figure 10–6

Item	Part No.	Description	Qty.	Notes
1	990880	Bearing	1	
2	731104	Bolt - Cap, 4 x 12 mm	1	
3	990879	Linkage - Actuator	1	
4	990882	Pin	1	
5	990881	Hub	1	
6	990883	Cam	1	
7	2B6355	Nut	1	
8	1C0051	Screw - 4 x 6 mm	2	
9	2B6421	Screw - Pan head, 4 x 35 mm	4	
10	990884	Gearbox	1	
11	990885	Motor - Actuator drive	1	
12	2B6416	Screw - Pan head, 3 x 15 mm	6	
13	256700	Screw - Pan head, 3 x 10 mm	4	
14	990886	Switch - Window open	2	
15	990887	Bracket - Switch mount	2	
16	2B6357	Frame	1	
17	2B6343	Plate - Ground	1	
18	732335	Screw - Pan head, 4 x 8 mm	2	
19	990898	Transformer	1	
20	990895	Switch - Voltage selector	1	
21	990896	Fuse - 3 A, Model 4/4SL	1	
21	990897	Fuse - 1 A, Model 4L	1	
22	2B6360	Cap - Voltage selector	1	
23	2B6407	Screw - Flat head, 3 x 10 mm	8	
24	2B6356	Microswitch	1	
25	2B6378	Stopper - Rod, left	1	
26	2B6380	Spring	1	
27	2B6408	Screw - Flat head, 4 x 10 mm	4	
28	2B6387	Pin	1	
29	2B6390	Microswitch	1	
30	2B6389	Bracket - Window detector	1	
31	2B6361	Spring	1	
32	2B6362	Pin B	1	
33	2B6363	Pin A	1	
34	2B6388	Pin - Open	1	
35	2B6364	Spring - Pin	1	
36	2B6365	Roller	1	
37	2B6367	Stay	1	
38	2B6366	Pin - Roller	1	
39	2B6368	Stiffener - Pin	1	
40	2B6370	Stopper - Rod, right	1	
41	2B6371	Stopper - Bearing	2	

Figure 10-7 Actuator, Switches, Fuses, and Transformer



H139_0036ECA
H139_0036EA

Figure 10–7

Item	Part No.	Description	Qty.	Notes
42	2B6372	Bearing - Slide	2	
43	2B6374	Bracket - Stay	1	
44	2B6373	Pin - Stay linkage	1	
45	2B6386	Spring	1	
46	2B6369	Stopper	1	
47	2B6419	Screw - Pan head, 4 x 12 mm	4	
48	2B6379	Microswitch	1	
49	2B6385	Guide - Cassette	1	
50	654373	Screw - Pan head, 2 x 10 mm	2	
51	2B6384	Spring	1	
52	2B6383	Pin - Microswitch	1	
53	234905	Screw - Pan head, 2 x 5 mm	2	
54	2B6381	Ring - Switch	1	
55	2B6375	Mount - Pin traveler	1	
56	2B6382	Bracket - Microswitch	1	
57	1C0068	Stay Unit Assembly	1	##Includes items 8, 23, 25 - 56, 58, 59##
58	2B6376	Rod	1	
59	2B6377	Rod	1	

This page is intentionally blank.